



Data Sheet

Pressure switch and Thermostat Type **KP** and **KPI**

For industrial applications



The KP and KPI pressure switches and thermostats are used for control, monitoring and alarm systems in a wide variety of industry applications.

KP pressure switches are mainly used for gaseous fluid whereas KPI pressure switches are more for liquid and gaseous fluid. The products are available in IP30 enclosure as well as IP55 enclosure.

The KP pressure range include special designed pressure switches and limiters for steam boilers and other heating applications.

For water pump control and protection (dry run) the dual pressure switch KP44 is suitable and secure improved life time of the water pump.



Features

Features

- Wide setting range
- Shock and impact resistant
- Snap action electrical contacts minimize chatter, bounce, and wear, and ensure long term electrical and mechanical reliability
- Small dimensions space saving and easy to install in panels
- Electrical connection from front of the unit makes rack mounting easier and also saves space
- Suitable for alternating current and direct current
- Single pressure switches and thermostats are fitted with a single pole double throw contact system (SPDT)
- Can be used for both liquids and gases (KPI)
- Manual trip function enables electrical connections verification without any tools or pressure changes in the application
- Versions with automatic and manual reset available
- For demineralized water, there are special KP models with wetted parts made of stainless steel (AISI 316L)



Product specification

Technical Data

Single pressure switch


Table 1: Single pressure switch

Table 1. Single pi	cooure owner							
Description		KP 35, KP 36	KPI 35, KPI 36	KPI 38	KP 34, KP 35, KP 36, KP 37 boiler version			
Ambient temperature	[°C]	-40 – 65 °C (for max. 2 hou	-40 – 65 °C (for max. 2 hours up to 80 °C)					
Media temperature [°C]	-40 – 100 °C						
Fluid		Gaseous media	Gaseous media and	liquids	Steam, air, gaseous media & liquids			
Parts in contact with	Bellows	Phosphor bronze or Stainless steel	Phosphor bronze		Stainless steel			
fluid	Pressure connector	Free-cutting steel (nickel plated) or Stainless steel	Brass	Free-cutting sto	eel (nickel plated)			
Contact system		Line <u>~ □ • • • • • • • • • • • • • • • • • • </u>	SPDT Line $\simeq \frac{4}{16A} \otimes \frac{8}{100}$ $2 \otimes \frac{1}{100}$					
		Single-pole double throw (SPDT)						
Contact load, Silver		Alternating current: AC-1: 16 A, 400 V AC-3: 16 A, 400 V AC-15: 10 A, 400 V	Alternating current: AC-1: 10 A, 440 V AC-3: 6 A, 440 V AC-15: 4 A, 440 V		Alternating current: AC-1 : 16 A, 400 V AC-3 : 16 A, 400 V AC-15 : 10 A, 400 V			
		Direct current: DC-13: 12 W, 220 V	Direct current: DC-13: 12 W, 220 V		Direct current: DC-13: 12 W, 220 V			
Contact load, Gold plan	ted contact set	See Table 6						
Enclosure, IP30 grade		Unit must be mounted on	a flat surface / a flat	fitting and all un	used holes covered			
Enclosure, IP44 grade		Mounted as IP30 plus fitti	ng of top cover, code	no. 060-109766				
Enclosure, IP55 grade		Unit mounted in a special IP55 enclosure, code no. 060-033066 or 060-062866						
Cable entry		Rubber cable gland entry for 6 – 14 mm diameter cables						
Mounted on back plate	e / wall bracket	Vibration proof in the range 0 – 1000 Hz, 4 g [1g = 9.81 m/s^2]						
Mounted on angle bra	cket	Not recommended in area	as where vibrations o	ccur				

Table 2: Contact system and application

rable 2. Contact system and application		
Switch type – single pole double throw	Switch action	Application
SPDT 4 M Significant 16A 1	Terminal 1 – 4 close high and open low Terminal 1 –2 can be used as low pressure alarm	Low pressure cut-out
SPDT	Terminal 1 – 2 open high and close low Terminal 1 – 4 can be used as high pressure alarm	High pressure cut-out





Cut-in and cut-out pressures of the system should always be checked with an accurate pressure gauge.

Pressure setting for switches with automatic reset.



- Set the cut-in pressure on the "CUT-IN" scale (range scale).
- Set the differential on the "DIFF" scale.

The cut-out pressure must be above absolute vacuum ($p_e = -1$ bar).

For high pressure switches the restart pressure is equal to cut-out pressure minus differential.

Pressure switches with manual reset

Set the cut-out presure on the "CUT-OUT" scale (range scale).

High pressure limiters can be manually reset when the pressure is equal to the stop pressure minus the differential.

1 NOTE:

For low pressure switches the restart pressure is equal to cut-out pressure plus differential value.

Dual pressure switch

Table 3: Dual pressure switch

Temperature	Range					
Ambient temperature [°C]	-40 - 65 °C (for max. 2 hours up to 80 °C)					
Media temperature [°C]	Max. 100 °C					
Fluid	Liquids					
Parts in contact with fluid	Bellows	Phosphor bronze, CuSn6				
Taris in contact with huid	Pressure connector	Free-cutting steel (nickel plated)				
Contact system	SSOJANGI VI SIGLE SIGLE STORY					
Contact load, Silver	Alternating current: AC-1: 16 A, 400 V AC-3: 16 A, 400 V AC-15: 10 A, 400 V Direct current:					
	DC-13: 12 W, 220 V					
IP level	IP22					
Cable entry	Rubber cable gland entry for 6 – 14 mm diameter cables					
Mounted on backplate or wall bracket	Vibration-proof in the range 0 – 1000 Hz, 4 g [1g = 9.81	l m/s²]				
Mounting on angle bracket	Not recommended for areas where vibration occurs					

Safety cut-out setting

The righthand bellows will automatically cut-out the pump at the safety cut-out setpoint. Automatic start-up, if any, will take place when the pressure has reached the level of 1 bar above the setpoint. Manual cut-in is made by lifting the impulse lever and releasing it again when the pressure has increased by min. 1 bar. The safety cut-out setpoint is normally determined by the static pressure (the water column). However, in order to avoid disturbing signal interaction, care should be taken to ensure that the safety cut-out setting is at least 1.5 bar lower than the control pressure cut-in setting. See table with pressure setting examples below

Table 4: Pressure settings

Required tap water pressure	≥ 2.3 bar	≥ 4.0 bar	≥ 5.0 bar	≥ 8.0 bar
Control pressure cut-out setting	3.0 bar	5.0 bar	8.0 bar	12 bar
Differential	0.7 bar	1.0 bar	3.0 bar	4.0 bar
Control pressure cut-in setting	2.3 bar	4.0 bar	5.0 bar	8.0 bar
Max. safety cut-out setting	0.8 bar	2.5 bar	3.5 bar	6.0 ⁽¹⁾ bar

^{(1) 6.0} bar is the normal max. setpoint

Control pressure settings

Control pressure cut-out setpoint is set on the lefthand pressure setting scale. The differential is set between 0.7 and 4 bar. The control pressure cut-in setting will be the cut-out control pressure less the differential.



Setting

Thermostats with automatic reset

Set the upper limit temperature on the range scale. Then set the differential on the DIFF scale. The temperature set on the range scale is also the temperature at which contact changeover re-occurs on rising temperature. The contacts changeover when the temperature has fallen to a value lower than that set on the DIFF scale.

If at lower settings the plant will not start/stop, the reason might be that the differential has been set too high.

Thermostats with minimum reset

Set the temperature on the range scale. The differential setting is fixed.

Min. reset units will restart after the temperature at the thermostat sensor has risen by a value greater than that of the fixed differential.

Thermostats with maximum reset

Set the stop temperature on the range scale. The differential setting is fixed.

Max. reset units will restart after the temperature at the thermostat sensor has fallen by a value greater than that of the fixed differential.

Dimensions [mm] and weights [kg]

Single pressure switch, type KP and KPI

Figure 9: KP 35, 36, KPI 35, 36, 38, Net weight 0.3 kg




Figure 10: IP55 enclosure




Figure 11: Wall bracket






Figure 12: Angle bracket









- Gives the maximum load
- В Acceptable load for the gold plating of the contact (DC-13)

Terminology

Range setting / Set point

The pressure range within which the unit will give a signal (contact changeover).

Differential

The difference between contact changeover on rising and falling pressure. The differential is a condition for stable automatic plant operation.

Manual reset

A unit with manual reset can only be restored to operational mode by activation of the external reset button. Min. reset units will restart after the pressure has risen by a value greater than that of the fixed differential. Max. reset units will restart after the pressure has fallen by a value greater than that of the fixed differential.

Automatic reset

Units with automatic reset restart automatically after stop.

Permissible operating pressure

The highest permissible constant pressure or pressure variation the unit can be exposed to.

Maximum test pressure

The maximum pressure applied in strength or leakage tests on heating system or components thereof.

Maximum working pressure

The maximum permissible pressure for safe functioning of a heating system or any of its parts.

Snap function

A specific contact force is maintained until snap is initiated. The time over which contact force reaches zero is a few milliseconds; therefore, contact bounce cannot occur as a result, for example, of slight vibrations before cut-out.

The snap-action contact system will continue to function even when micro-welds are created between the contacts during cut-in.

The force created to separate the contacts is strong, and instantly shears off all contact surface welds that have been created as the result of cut-in action.

These design features ensure that the cut-out point of the KP control remains very accurate and completely independent of the magnitude of the current load.

Current ratings:





AC – 1	The alternating current rating, in amperes, of the non-inductive, slightly inductive loads or resistive furnaces
AC – 3	The alternating current rating, in amperes, of the squirrel-cage motors: starting, plugging, inching
AC – 15	The alternating current rating, in amperes, of electromagnetic loads (>72VA)
DC – 13	The direct current rating, in amperes, of electromagnets



Ordering

Pressure switch, type KP and KPI

Table 7: Pressure switch, types KP 35 and KP 36

Туре	Setting range P _e	Differential	Permissible oper- ating pressure P _e	Max. test pres- sure	Pressure connec- tion	Contact material	Code no.
	[bar]	[bar]	[bar]	[bar]	tion		
	-0.2 – 7.5	0.7 – 4.0	17	22	G 1/4 A	silver	060-113366 060-113391 ⁽¹⁾
KP 35	-0.2 – 7.5	0.7 – 4.0	17	22	G 1/4 A	gold-plated	060-504766
	-0.2 – 7.5	0.7 – 4.0	17	22	G 1/4 A	silver	060-538666 ⁽²⁾
	-0.2 – 7.5	0.7 – 4.0	17	22	G 1/4 A	silver	060-450366 ⁽³⁾
	2.0- 14.0	0.7 – 4.0	17	22	G 1/4 A	silver	060-110866 060-110891
	2.0- 14.0	0.7 – 4.0	17	22	G 1/4 A	gold	060-113766
KP 36	2.0 - 14.0	0.7 - 4.0	17	22	G 1/4 A	silver	060-450166 ⁽³⁾
	2.0- 14.0	0.7 – 4.0	17	22	G 1/4 A	silver	060-538766(2)
	4.0 – 12.0	0.5 – 1.6	17	22	G 1/4 A	silver	060-122166
	4.0 – 12.0	0.5 – 1.6	17	22	G 1/4 A	gold	060-114466

⁽¹⁾ Available only in Asia market (2) IP55 transparent enclosure

Table 8: Pressure switch, types KPI 35 - KPI 38

Туре	Setting range P _e	Differential	Permissible oper- ating pressure P _e	Max. test pres- sure	Pressure connec-	Contact material	Code no.	
	[bar]	[bar]	[bar]	[bar]	tion			
	-0.2 – 8.0	0.4 – 1.5	18	18	G 1/4 A	silver	060-121766	
KPI 35	-0.2 – 8.0	0.4 – 1.5	18	18	G 1/4 A	gold-plated	060-316466	
KPI 35	-0.2 – 8.0	0.5 – 2.0	18	18	G 1/4 A	silver	060-121966	
	-0.2 – 8.0	0.4 – 1.5	18	18	G 1/4 A	silver	060-315766 (4)	
	4.0-12.0	0.5 – 1.6	18	18	G ¼ A	silver	060-118966	
KPI 36	4.0-12.0	0.5 – 1.6	18	18	G ¼ A	gold-plated	060-113866	
KF1 30	2.0 – 12.0	0.5 – 1.6	18	18	G ¼ A	silver	060-316966	
	2.0 – 12.0	0.5 – 1.6	18	18	G 1/4 A	silver	060-319366 ⁽⁵⁾	
KPI 38	8.0 – 28.0	1.8 – 6.0	30	30	G 1/4 A	silver	060-508166	
	8.0 – 28.0	1.8 – 6.0	30	30	G 1/4 A	silver	060-541866	

⁽⁴⁾ IP55 transparent enclosure

Table 9: Pressure switch, types KP 34 - KP 37, boiler version

Туре	Setting range p _e	Differential	Reset	Pressure connection	Max. test pres- sure	Contact material	Code no.	
	[bar]	[bar]		[bar]	[bar]			
KP 34	0.1 – 1.0	0.1 – 0.4	Automatic	G ½ A	4.0	silver	060-216466	
NP 34	0.1 – 1.0	0.2	Manual	G ½ A	4.0	silver	060-216366	
KP 35	0.4 – 3.4	0.4 – 2.2	Automatic	G ½ A	10	silver	060-216666	
KF 33	0.4 – 3.4	0.5	Manual	G 1/2 A	10	silver	060-216566	
KP 36	1.0 – 10.0	0.7 – 4.0	Automatic	G 1/2 A	17	silver	060-215966	
NP 30	1.0 – 10.0	0.7	Manual	G 1/2 A	17	silver	060-216066	
KP 37	4.0 – 20.0	1.8 – 3.1	Automatic	G 1/2 A	28	silver	060-216166	
	4.0 – 20.0	3.0	Manual	G ½ A	28	silver	060-216266	

⁽³⁾ Stainless steel version, IP55 non-transparent enclosure

⁽⁵⁾ IP55 non-transparent enclosure



Table 10: Pressure switch, type KP 44

Pressur	e range	Differ	ential	Permissible operating		D	Camba at marks	
Control [bar]	Safety [bar]	Control [bar]	Safety [bar]	pressure p _e [bar]	Max. test pressure [bar]		Contact mate- rial	Code no.
2.0 – 12.0	0.5 – 6.0	0.7 – 4.0	1.0	Left side: 17 Right side: 17	Left side: 25 Right side: 19	2 × G 1/4 A	Silver	060-001366

Thermostat, type KP

Table 11: Thermostat, types KP 75 – KP 81

Туре	Setting range [°C]	Differential [°C]	Max. sensor temperature [°C]	Capillary tube length [m]	Contact material	Code no.
KP 75	0 – 40	3 – 10	80	Room sensor	silver	060L121266
KP 75	0 – 40	3 – 10	80	Room sensor	gold-plated	060L117166
KP 78	30 – 90	5 – 15	150	2	silver	060L118466
KP 79	50 – 100	5 – 15	150	2	silver	060L112666
KP 81	80 – 150	7 – 20	200	2	silver	060L112566
KP 81	80 – 150	7 – 20	200	3	silver	060L118366
KP 81	80 – 150	7 – 20	200	5	silver	060L117066
KP 81 (max. reset)	80 – 150	8 (max. reset)	200	2	silver	060L115566

Accessories for KP pressure switches

Table 12: KP pressure switches

Table 12: KP pressure			
Part	Symbol	Description	Code no
irackets with mounting crews and washers		Wall bracket for KP Angle bracket for KP	060-105566 060-105666
crewed cable entry		PG 13.5 with special nut For 6 –14 mm diameter cables	060-105966
ealing screw		For sealing the setting on KP	060-105766
op cover		If a bracket is mounted on the backplate of the housing, the KP thermostats will have an IP44 grade of enclosure. The cover protects the setting spindles	060-109766
Protective cap		Protective cap for KP pressure switches and thermostats. To protect the unit against rain and humidity. Grade of enclosure: IP44 Material: Polyethylene Max. ambient temperature: 65 °C Min. ambient temperature: -40 °C	060-003166
P55 nontransparent en- losure		If the unit risk being exposed to heavy water influence a better grade of enclosure can be achieved when mounting product in a special IP55 enclosure	060-033066
P55 transparent enclo- ure		If the unit risk being exposed to heavy water influence a better grade of enclosure can be achieved when mounting product in a special IP55 enclosure	060-062866



Certificates, declarations, and approvals

The list contains all certificates, declarations, and approvals for this product type. Individual code number may have some or all of these approvals, and certain local approvals may not appear on the list.

Some approvals may change over time. You can check the most current status at danfoss.com or contact your local Danfoss representative if you have any questions.

Table 15: Certificates, declaration and approvals

Document name	Document type	Document topic	Approval authority
BK_W_0862_01_2018	Food and Health - Performance Certificate		PZH
RU Д-DK.ГА02.В.03367	EAC Declaration	EMC	EAC
RU C-DK.БЛ08.B.00063_18	Electrical - Safety Certificate	EMC/LVE	EAC
ELE-086320XG-003	Marine - Safety Certificate		RINA
UA.1O146.D.00075-19	UA Declaration	EMCD/LVD	LLC CDC EURO TYSK

- CE-marked in accordance with LVD 2014/35/EU: EN 60947-1, EN 60947-4-1, EN 60947-5-1
- Underwriters Laboratories Inc., UL
- China Compulsory Certificate, CCC (excluding boiler versions)



Online support

Danfoss offers a wide range of support along with our products, including digital product information, software, mobile apps, and expert guidance. See the possibilities below.

The Danfoss Product Store



The Danfoss Product Store is your one-stop shop for everything product related—no matter where you are in the world or what area of the cooling industry you work in. Get quick access to essential information like product specs, code numbers, technical documentation, certifications, accessories,

Start browsing at store.danfoss.com.

Find technical documentation



Find the technical documentation you need to get your project up and running. Get direct access to our official collection of data sheets, certificates and declarations, manuals and guides, 3D models and drawings, case stories, brochures, and much more.

Start searching now at www.danfoss.com/en/service-and-support/documentation.

Danfoss Learning



Danfoss Learning is a free online learning platform. It features courses and materials specifically designed to help engineers, installers, service technicians, and wholesalers better understand the products, applications, industry topics, and trends that will help you do your job better.

Create your Danfoss Learning account for free at www.danfoss.com/en/service-and-support/learning.

Get local information and support



Local Danfoss websites are the main sources for help and information about our company and products. Find product availability, get the latest regional news, or connect with a nearby expert—all in your own language.

Find your local Danfoss website here: www.danfoss.com/en/choose-region.

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or further that the sending Dantoss reserves the right to after its produce miniocities and the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.